



LUTEC



1	2	3
4	5	6
7 Brief: Slide the switch to ON, when at night, the light will illuminate about 5 ~ 90 seconds (by the Time setting) when motion in the cover area (by the Sensitivity setting) is detected. Note: Slide the switch to TEST, just cover the Photocell, and the light will illuminate in daytime when motion is detected. Sensitivity Time Photocell Switch Connector		
8	9	10 The cable for the solar panel is 5m long, 2m inside the panel, and can be pulled out if necessary
11 Please charge the lamp under the Sun 30 minutes before illuminating it	12 HEIGHT (h) 2m DISTANCE 15m	


Achtung:

- * Die Batterie nicht in Feuer legen - Explosionsgefahr
- * Die Batterie nicht in Wasser legen
- * Das Solarpanel an einem sonnigen Ort platzieren. Ladezeit 3 Stunden bei sonnigem, Wetter 5 Stunden hinter einer Glasscheibe.
- * Wir empfehlen, den Akku vor erstem Gebrauch 24 Stunden zu laden: Schalter auf OFF und Laden lassen, dann Schalter auf AUTO -> Lampe leuchtet in Verbindung mit Dunkelheit und Bewegung - Schalter auf ON -> Lampe leuchtet permanent.

Important Safety Information:

- Do not put the battery in fire - it may explode.
- Do not immerse into water.
- Do not expose the light to fire or intense heat as the battery may explode.
- The solar charger board should be set in a sunny area, where maximum sunlight can be collected. Typically, the solar board should face a direction (south) where sunlight can charge the board for at least 3 hours per day (5 hours per day if behind glass). It is suggested to charge the light for 24 hours before first use.

AKKU-Wechsel / Battery-Change

**Service:**

Germany (DE), Austria (AT), Switzerland (CH) :

www.ecolight.biz / +49 228 9691090

ECO-LIGHT Leuchten GmbH

Bücheler Weg 27 - D-53347 Alfter

France(FR): www.lutec-france.com / +33 04 75602568

- are members of

Lutec Group

CN8, Far East Industry Park , Yuyao, China

www.lutec.net

40K00009018c